




Trainer Field Guide





GUESS

CUESS S

Johto Edition

zanzoon

Johto Edition

Think of a Pokémon, I'll Guess It!

Hello Trainer! Are you ready for your Pokémon journey?

TRAINER GUESS is an amazing guessing game that lets you collect Pokémon. Think of a Pokémon, and it will try to guess it by asking you questions. If TRAINER GUESS, quesses it right, the Pokémon will be added to your electronic collection!

NOTE: Once TRAINER GUESS is removed from package, pull the "Try Me" tag to start your collection.

HOW TO PLAY WITH TRAINER GUESS:

Press the Poké Ball's button to turn it on. The Poké Ball will talk to you and ask you to think of a Pokémon.

Say "OK" in a clear voice when you've thought of Pokémon and are ready to play.

TRAINER GUESS will ask you several questions in order to guess the Pokémon you've chosen. You can answer with:

- "YES"
- "NO"
- "I DON'T KNOW"
- "IT DEPENDS"

If you did not hear the question, you can ask the Poké Ball to repeat it by saying: "SAY IT AGAIN".

If you want to change your previous answer, you can ask the Poké Ball to go back by saying: "GO BACK", when the Poké Ball is silent.

The Poké Ball will then go back and ask you the previous question again. You can go back as far as the first question asked.

If you don't want to play anymore, press the Poké Ball's button to switch it off.

If the toy is left inactive for 60 seconds it will switch itself off.

TRAINER FIELD GUIDE:

Your field guide will help you a lot during your journey. Use it to discover new Pokémon and learn more about them. In case you're not sure of an answer, check it in your field guide! If you give too many wrong answers, the Poké Ball may not find your Pokémon. And when a Pokémon is added to your electronic collection, don't forget to also check it off in your field guide.

* Field guides for Kanto & Johto regions are also available to download at: www.zanzoon.net/Pokemon/quide

CHECKING YOUR COLLECTION:

You can check your collection anytime during the game simply holding down the button for 2 seconds. The Poké Ball will then stop the guessing game and tell you how many Pokémon you have, how many are left, and it will even give you the list of all the Pokémon you've collected.

RESET YOUR COLLECTION:

You can start a brand new collection at anytime by resetting the game. With adult supervision, use a screwdriver to open the Poké Ball battery compartment. Then, press and hold the Poké Ball's button. Keep holding it down while you close the battery compartment again and wait to hear "We Now Have O Pokémon." before releasing the button. Your collection has now been reset.

Wobbuffet **PSYCHIC**

HEIGHT 4'03" (1.3 m) WEIGHT 62.8 lbs (28.5 kg)

DOES NOT EVOLVE



Xatu

PSYCHIC - FLYING HEIGHT 4'11" (1.5 m) WEIGHT 33.1 lbs. (15.0 kg)

NATU > XATU



Wooper

WATER - GROUND HEIGHT 1'04" (0.4 m) WEIGHT 18.7 lbs. (8.5 kg)


EVOLUTION WOOPER > QUAGSIRE



Yanma

TYPE BUG-FLYING HEIGHT 3'11" (1.2 m)

EVOLUTION DOES NOT EVOLVE



TRANSFER YOUR KANTO COLLECTION

If you own the Kanto Ball and have already collected the 151 Pokémon in the Kanto Ball, you can transfer them to your new Johto Ball!

- 1. Make sure that both Poké Balls are close to each other!
- 2. Turn on your Johto Ball.
- 3. Press and hold the button of the Johto Ball to access your collection.
- 4. While the Johto Ball is telling how many Pokémon there are in your collection, press the button again and hold it.
- 5. Turn on your Kanto Ball.
- 6. Quickly press and hold the button of your Kanto Ball to access the collection (you should do that within 10 seconds after the Kanto Ball is on).



©2018 The Pokémon Company International ©1995-2018 Nintendo/Creatures Inc./GAME FREAK inc. TM, ®, and character names are trademarks of Nintendo. Trainer Guess: Johto Edition @2018 Zanzoon. All rights reserved. ZANZOON 90 rue de Villiers – 92300 Levallois-Perret - France zanzoon@zanzoon.net - www.zanzoon.net

BATTERY INSTRUCTIONS

Keep these instructions handy for future reference

Please follow the guidelines below to avoid damaging the pad: • Store the toy in a dry place, keep out of direct sunlight and away from heat source. . Do not dismantle the toy in any way. • Keep the toy clean by wiping it with a slightly damp cloth. • Remove the batteries when the toy will not be in use for an extended period of time.

· Non-rechargeable batteries are not to be recharged. · Batteries should always be replaced under adult supervision. • Rechargeable batteries are only to be charged under adult supervision. • Rechargeable batteries are to be removed from the toy before being charged. • The supply terminals are not to be short-circuited. • Different types of batteries or new and used batteries are not to be mixed. • Batteries are to be inserted with the correct polarity.

· Exhausted batteries are to be removed from the toy. · Dispose of batteries safely. • Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries during long periods of non-use.
Do not throw used batteries into fire or nature, or dispose of them as household waste. Take them to a local collection point or recycling facility.

BATTERY INSTALLATION

Using a Phillips/crosshead screwdriver (not included). loosen the screws in the battery compartment cover (screws stay attached to cover.) Remove the cover, insert 3 x 1.5V "AAA" size batteries. Replace cover and tighten screws.

The batteries provided with this toy are only sufficient to enable testing in store. They are not long-life batteries. To ensure optimal performance we recommend the exclusive use of alkaline batteries. Rechargeable batteries are not recommended as they do not provide adequate power. Only batteries specified for this product should be used.

If voices become slow or distorted: replace the batteries



This device is stamped with a «selective sorting» symbol relating to the disposal of electric and electronic equipment. This means the product must be dealt with by a system of selective collection in accordance with European directive 2002/96/CE, so it can be recycled and reduce the impact on the environment. For more details, please contact your local administration.

Electronic products which are not subject to special collection are potentially dangerous for the environment and public health, as they contain dangerous substances.




Lead (Pb) is more than 0,004%. Please remove exhausted batteries from the product and use designated collection points or recycling facilities when disposing of batteries.




Warning! Not suitable for children under

Item No: 1118105







WEIGHT 11 lbs (5.0 kg)

EVOLUTION DOES NOT EVOLVE



HEIGHT 2'0" (0.61m) WEIGHT 20.9 lbs (9.5 kg)

TOTODILE > CROCONAW > FERALIGATR





TYPE NORMAL HEIGHT 5'11" (1.80m) WEIGHT 277.3 lbs (125.8 kg)

EVOLUTION TEDDIURSA > URSARING














TYPE ROCK

EVOLUTION

DOES NOT EVOLVE

HEIGHT 3'11" (1.19m)

WEIGHT 83.8 lbs (38.0 kg)





TYPE ICE - PSYCHIC

HEIGHT 1'4" (0.41m)

EVOLUTION

EVOLUTION

DOES NOT EVOLVE

EVOLUTION

SNUBBULL > GRANBULL

SMOOCHUM > JYNX

TYPE DARK-ICE

HEIGHT 2'11" (0.89m)

WEIGHT 61.7 lbs (28.0 kg)

WEIGHT 13.2 lbs (6.0 kg)

Sneasel






HEIGHT 2'7" (0.79m) WEIGHT 18.7 lbs (8.5 kg) **EVOLUTION**

SUNKERN > SUNFLORA







WEIGHT 105.8 lbs (48.0 kg)

TYROGUE > HITMONLEE OR HITMONCHAN OR HITMONTOP

EVOLUTION













DARK - FLYING

HEIGHT 1'8" (0.51m)

EVOLUTION

EVOLUTION

NATU > XATU

DOES NOT EVOLVE

WEIGHT 4.6 lbs (2.1 kg)

Natu

Noctowl

NORMAL - FLYING

TYPE PSYCHIC - FLYING

HEIGHT 0'8" (0.20m)

WEIGHT 4.4 lbs (2.0 kg)

HEIGHT 5'3" (1.60m)

EVOLUTION

HOOTHOOT > NOCTOWL

WEIGHT 89.9 lbs (40.8 kg)





